



## **Light Flicker Issue**

Article ID: GV15-14-03-24-m Revision Date: 3/31/2016

## **Applied to**

**GV-IP** Camera

## **Symptom**

The flicking images happen when you expose the camera to the direct light, or when the light from any reflective materials, such as marble floors or big glass windows, is reflected on the camera image.

In the following example, we used a white color paper to reveal the light flicker. See the pale yellow lines on the paper.







## Solution

To solve this light flicker issue: (1) change the Flicker less settings; (2) minimize exposure to light; (3) change the Brightness settings; (4) enable Auto Iris; and/or (5) change the cover on the camera. Refer to the steps below and follow the instructions to reduce light flicker.

1. Change the frequency of your camera's image to match the frequency of light sources.

On the Live View window of GV-IP Camera, select the **Expand** icon , select the **Menu** icon , select **Camera Adjustment**, select **50 Hz** or **60 Hz** under Flicker less, and select **Save**.

Live View							
In this section you can see a	nd configure the default camera vi	ew.					
Live View Configuration							
			0	1			
04:51:51	Play	<u>_</u>	Camera ad	ajustment			
			Default	Save	JN 8		
			Auto	•			
			Flicker less				
		decide la como	50 Hz	<b></b>	Ξ		
			60 Hz				
			Normal	<b>•</b>			
			Slowest Shutter Speed	l l			
			Auto	•	~		
				_	-		

**Note:** You may check the power utility to determine which electricity frequency is used. In the US it's 60 Hz and in most of Europe it's 50 Hz.

2. Try to avoid direct exposure to sources of light.





3. Change the brightness of your camera's image to determine whether the flicker issue can be reduced.

On the Live View window of GV-IP Camera, select the **Expand** icon , select the **Menu** icon , select **Camera Adjustment**, adjust the brightness of the image under Brightness, and select **Save**.

Live View					
In this section you can see a	nd configure the default camera vie	w.			
Live View Configuration					
08:14:51	Play	<	Camera ad	djustment	
			Default	Save	
			Brightness		<b>^</b>
			<b>i</b> (		=
			Contrast		
		0000000000	0	_	
			Saturation	1	
Contraction of the local division of the loc			Sharpness		
	and the second second			)]	-





4. When the above three solutions do not work, you may enable **Auto Iris** if your camera supports the function.

On the Web interface of GV-IP Camera, select Video and Motion, select Video Setting, select Streaming 1 and enable Auto Iris. The Message from webpage window appears. Click OK and click Apply.

			1 In a second switch is and slight in stallard	
<b>GeoUision</b>		Post-alarm recording time	(1~30)	
Video and Motion		Split interval	5 V minutes	
	Live View	Record audio		
	Video Settings	Continue recording to the local storage when live view is		
	Streaming1	accessed		
	Streaming2			
	Motion Detection	OSD Setting		
	Privacy Mask			
	Tant Quardan	n this section you can set up Text Overlay		
	Iampering Alarm			
	Visual Automation	Overlaid with date stamps		
	I/O Control	Overlaid with time stamps		
	Events and Alerts			
	Monitoring	TV-Out Massage from webpage		
	Recording Schedule	Message from webpage		
	Network	Signal Format ONTSC		
	Wanagement	Note the Auto Iris ca	nnot be applied to all scenes. Do you want	
	Logout	LED Control to enable Auto Iris?		
~ ~				
		Ready LED   Enable		
			OK Cancel	
		Special View Setting	OK	
		Additional functions for the service		
		D/N		
		Auto Soncitivity 5		
		Black and White		
		Color		
		IR Check Function: <ul> <li>Off</li> <li>On</li> <li>Origger IR by D/N</li> </ul>		
		Auto Iris   Enable  Disable		
		BLC  ● Off  ○ On		
	~	, they		

5. For **GV-MFD**, **GV-MDR**, **GV-UBX** and **Target Series (for GV-EBX 1100**, **GV-EFD 1100**), since there is no Auto Iris option, you may replace the transparent cover to a smoked cover to reduce light transmission.



The figure above is a sample of a GV-MFD and GV-MDR Series smoked cover.

For the optional cover, please contact our sales representative for more information.