

[FAQ]

Why is user able to Telnet access AS400 controller without any ID/Password verification?

Release Date: 11/11/2015

Applied to

GV-AS100/GV-AS110/GV-AS120/GV-AS400

Question

Why is user able to Telnet access AS400 controller without any ID/Password verification?

Answer

Due to the lack of network security, user is able to Telnet access above models without any ID/Password verification. Beta F/W is available on request which disables Telnet function for above controllers (Link: http://ftp.geovision.tw/ftp/aaron/AS400Unit_V107_20150729.zip). All current and new models will have Telnet disabled from F/W v1.3 onwards.

For any question on the information provided, please feel free to submit your question to our support window at support@geovision.com.tw