
[FAQ]

How to adjust the frame rate of cameras on Control Center?

Release Date: 7/09/2015

Applied to:

Control Center

Question:

How to adjust the frame rate of cameras on Control Center?

Answer:

Please go to the desired camera's web interface to do the FPS setting.

It is unable to change the FPS of cameras through Control Center.

For any question on the information provided, please feel free to submit your question to our support window at support@geovision.com.tw