

[FAQ]

How to authorize the channels for GV-Mobile Applications' users?

Article ID: GV13-04-01-k

Release Date: 04/01/2013

Applied to

GV-Mobile Applications

Question


How to authorize the channels for GV-Mobile Applications' users?

Answer

To authorize your user account from the GV-DVR/NVR System for remote viewing on the GV-Mobile Applications, follow the steps below.

Note: Only the Supervisor account is authorized to access the Password Setup.

1. On the main screen, click the **System Configure** button, select the **Password Setup** and select **Local Account Edit**. This dialog box appears.



2. Select the desired cameras for live video viewing. The Supervisor is able to authorize Guest, User, and PowerUser to access specific camera's channel.
3. Click **OK**.

For details, see *1.5 Account and Password in Multicam Digital Surveillance System V8.5.6.0 User's Manual* on Software DVD.