

[FAQ]

How to display text stamps in 16 / 32 screen divisions in Multi View?

Article ID: GV11-07-25-j

Release Date: 07/25/2011

Applied to

Multi View of WebCam Server

Question


My Multi View can only display text stamps (camera name, date and time) on live images in the 4/6/8/9/10/13 screen divisions. How do I display text stamps in 16 or 32 screen divisions?

Answer

The symptom may occur because the video resolution is too low. To display text stamps on live images in 16 or 32 screen divisions, you have to set up the video resolution to be 320 x 240 or higher.

How to do

1. On the GV-System, click the **Network** button, select **WebCam Server** and click the **General** tab.
2. In the Frame Page Title Color section, select a color for the camera name, date and time stamps. Click **OK**.



3. In the Multi View window, click the **Quality** button, select **Change All Quality**, select a video codec, and select a resolution of **320 x 240** or higher.

